
Gliderol TM390
Programming Guide



Genuine TM305c



Note: Pressing the enter button for 5 seconds or more will erase all handset data from your operator - be careful not to press the enter key for longer than neccessary

Programming Your Remote Control

1 Press and hold the "Enter" button for two seconds to access the operator menu
2 Use the arrow keys to select the Learn option and press enter. The unit will beep 3x.
3 Press any button on the remote. The motor will beep once if successfull.
4 Allow three seconds for the unit to exit setup mode. Your remote will then be ready for operation!

Clearing The Codes From Your Motor

1 Press and hold the enter button for 5 seconds
2 Test that your remote no longer operates the motor

For technical support, see our website below.
Please have the model number of your remote control and garage / gate opener before calling.

www.autoopeners.com.au